

Relaiskanäle 23 cm Band

| Kanal | Frequenz MHz | | Kanal | Frequenz MHz | |
|--------|--------------|----------|--------|--------------|----------|
| | Eingabe | Ausgabe | | Eingabe | Ausgabe |
| RS01 * | 1270.025 | 1298.025 | RS01-* | 1270.025 | 1242.025 |
| RS02 * | 1270.050 | 1298.050 | RS02-* | 1270.050 | 1242.050 |
| RS03 * | 1270.075 | 1298.075 | RS03-* | 1270.075 | 1242.075 |
| RS04 * | 1270.100 | 1298.100 | RS04-* | 1270.100 | 1242.100 |
| RS05 * | 1270.125 | 1298.125 | RS05-* | 1270.125 | 1242.125 |
| RS06 * | 1270.150 | 1298.150 | RS06-* | 1270.150 | 1242.150 |
| RS07 * | 1270.175 | 1298.175 | RS07-* | 1270.175 | 1242.175 |
| RS08 | 1270.200 | 1298.200 | RS08- | 1270.200 | 1242.200 |
| RS09 | 1270.225 | 1298.225 | RS09- | 1270.225 | 1242.225 |
| RS10 | 1270.250 | 1298.250 | RS10- | 1270.250 | 1242.250 |
| RS11 | 1270.275 | 1298.275 | RS11- | 1270.275 | 1242.275 |
| RS12 | 1270.300 | 1298.300 | RS12- | 1270.300 | 1242.300 |
| RS13 | 1270.325 | 1298.325 | RS13- | 1270.325 | 1242.325 |
| RS14 | 1270.350 | 1298.350 | RS14- | 1270.350 | 1242.350 |
| RS15 | 1270.375 | 1298.375 | RS15- | 1270.375 | 1242.375 |
| RS16 | 1270.400 | 1298.400 | RS16- | 1270.400 | 1242.400 |
| RS17 | 1270.425 | 1298.425 | RS17- | 1270.425 | 1242.425 |
| RS18 | 1270.450 | 1298.450 | RS18- | 1270.450 | 1242.450 |
| RS19 | 1270.475 | 1298.475 | RS19- | 1270.475 | 1242.475 |
| RS20 | 1270.500 | 1298.500 | RS20- | 1270.500 | 1242.500 |
| RS21 | 1270.525 | 1298.525 | RS21- | 1270.525 | 1242.525 |
| RS22 | 1270.550 | 1298.550 | RS22- | 1270.550 | 1242.550 |
| RS23 | 1270.575 | 1298.575 | RS23- | 1270.575 | 1242.575 |
| RS24 | 1270.600 | 1298.600 | RS24- | 1270.600 | 1242.600 |
| RS25 | 1270.625 | 1298.625 | RS25- | 1270.625 | 1242.625 |
| RS26 | 1270.650 | 1298.650 | RS26- | 1270.650 | 1242.650 |
| RS27 | 1270.675 | 1298.675 | RS27- | 1270.675 | 1242.675 |
| RS28 | 1270.700 | 1298.700 | RS28- | 1270.700 | 1242.700 |

Hinweis: Die "RSxx-" - Kanäle werden nur in Sonderfällen vergeben.
Bei 1242.025 - 1243.700 MHz können die Ausgabefrequenzen bei Bedarf für Linkstrecken zwischen Relais vergeben werden
"*" = Kanal wird nur fuer Sonderanwendungen vergeben.